

HOW TO FIX LOOSE CABINET HINGES AND HANDLES

For this maintenance project, you will need:

- ✓ A screwdriver
- ✓ Lubricating spray
- ✓ A microfibre cloth
- ✓ A scourer
- ✓ Multi-purpose cleaner


Loose Handles

1. Simply open the door.
2. Locate the loose screw, and tighten with the appropriate screwdriver. Avoid using power tools as this can cause damage to the panel and hardware.

Loose Hinges

1. If it is the hinges that need tightening, simply locate the clip at the back, and carefully remove, revealing the two outer screws. Carefully tighten these until the hinge is firmly in place. Reattach the hinges by aligning, then clipping down at the back.
2. If there is dirt, grime or surface rust present, it may be worth cleaning hinges as well as the surrounding area, with an appropriate cleaner.

Avoid using power tools as this can cause damage to the panel and hardware.



HOME IN PLACE TENANTS PLEASE REFER TO YOUR
RESIDENTIAL TENANCY AGREEMENT TO SEE IF THIS TYPE OF
MAINTENANCE IS YOUR RESPONSIBILITY.

